

LED LDR Troffer Retrofit Bracket Kit

Instruction Number: P-INT-X-418

Product Series: LDRE/LDRM 2' x 2' and 2' x 4'



WARNING! Risk of fire or electric shock. Luminaire wiring and electrical parts may be damaged when drilling for installation of LED retrofit kit. Check for enclosed wiring and components.

WARNING! Risk of fire or electric shock. LED Retrofit Kit installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation contact a qualified electrician.

WARNING! Risk of fire or electric shock. Install this kit only in the luminaires that have the constructions features and dimensions shown in the photographs and/or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.

WARNING! To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.

WARNING! Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.

CAUTION! Risk of fire. Consult a qualified electrician to ensure correct branch circuit conductor.

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. THE RETROFIT ASSEMBLY IS ACCEPTED AS A COMPONENT OF A LUMINAIRE WHERE THE SUITABILITY OF THE COMBINATION SHALL BE DETERMINED BY UL OR AUTHORITIES HAVING JURISDICTION. LUMINAIRE HOUSING BEING RETROFITTED MUST BE METAL IN ORDER TO PROVIDE APPROPRIATE PATH FOR BONDING.

Use this instruction to convert a recessed troffer lensed fluorescent to LED.

Components

- 1 LED Troffer Bracket Retrofit
- 2 Side Mounting Brackets

Tools Required for Installation

Wire cutters/strippers

Step-by-Step Instructions

1. Field installers are responsible for recognizing specific site requirements and making adjustments to assure a complete, functional installation.
2. Make all power connections using UL listed components.
3. Electrical connections must be made by a qualified electrician and in accordance with NEC and local codes.

- 1 Remove existing door frame (if installed) and lamps. If clearance permits, abandon ballast and socket bars inside the existing fixture. Otherwise remove these as needed. Dispose of lamps, door frame, and ballast properly. (See Fig. 1)
- 2 Lift luminaire housing and slide in both side mounting brackets between the housing and the T-Bar grid. (See Fig. 2) Lower luminaire onto mounting brackets.
- 3 Hang the LDR by its hinges on one of the mounting brackets. (See Fig. 3 and Fig. 4)
- 4 Install power disconnect (pre-attached to supplied power leads) to the line (black) and neutral (white) coming into the fixture. (See Fig. 5)
- 5 Wire the existing fixture ground wire to the supplied ground wire(s). If no ground wire exists from the power supply, add ground wire to the existing luminaire housing.
Note: The LDR must be properly grounded
- 6 Close the LDR and secure the latches. (See Fig. 6)
- 7 Reconnect the main power and test fixture.

