

LED Troffer Edge

Instruction Number: P-INT-X-412

Product Series: LTHE1

Use this instruction to install the LED Troffer Edge in new construction environments.

Components

- 1 LTHE1 Fixture

Items Required for Installation

-Cordless drill

Step-by-Step Instructions



WARNING!

Risk of fire or electric shock. To reduce risk of electrical shock, turn off power supply before installation or servicing.

1. Field installers are responsible for recognizing specific site requirements and making adjustments to assure a complete, functional installation.
2. Make all power connections using UL listed components.
3. Electrical connections must be made by a qualified electrician and in accordance with NEC and local codes.

- 1 Remove fixture from packaging.
- 2 Set the fixture into the T-Bar framework (See Fig. 1 and Fig. 2).
- 3 Remove the electrical cover plate from the back of the fixture (See Fig. 3).
- 4 Secure conduit and incoming power supply wires into electrical cover plate opening and make electrical connections per NEC and local codes (See Fig. 4).
- 5 Insert all wires carefully into the driver channel (do not pinch wires when closing). Reattach the electrical cover plate to the driver channel (See Fig. 5).
- 6 Restore power and test fixture.

If fixture is required to be fastened to T-Bar grid see below:

Use self supplied fasteners to secure the fixture body to the T-Bar framework (See Fig. A1 for an example of one of the provided factory locations-4 total per fixture, see Fig. A2 for use of screws and Fig. B for use of seismic clips attaching the fixture to the T-Bar framework).

